IHLEFABRICATIONS LLC®

INSTALLATION INSTRUCTIONS

ELEVATOR HEAD DOOR REINFORCEMENT HINGE PIN PLATES

CASE IH® FLAGSHIP SERIES



All **Ihle Fabrications** products are made in the USA using the best materials to provide quality auger liner replacement parts. **Ihle Fabrications** a family-owned agriculture and fabrication business and stands behind our craftsmanship.











HARDOX® WEAR PLATE

Hardox® Wear Plate is the world's leading abrasion-resistant (AR) steel. Enjoy the benefits of guaranteed toughness in our products made with Hardox® Wear Plate.



TOOLS NEEDED

Welder Drill Locking C-Clamps Washer

ITEMS INCLUDED

4 Hinge Plates

THANK YOU FOR YOUR BUSINESS

PH: 515-329-8050

IHLEFABRICATIONSLLC®

INSTALLATION INSTRUCTIONS

REINFORCEMENT HINGE PLATES

NOTE: When installing the Hinge Pin Plates installer will also need to modify the hinge pin to make it long enough. We recommend welding a washer to one end of the pin and redrilling a hole on the other end to fit the cotter key.

Step 1: Use a clamp to hold the plate tight against the Elevator Head.

Step 2: Stitch Weld along each side, where arrows below indicate.

Step 3: Repeat this for both sides.

NOTE: Depending on the year of the machine you may need the rounded corner or the squared set. Both are provided.



QUESTIONS?

REACH OUT TO OUR TEAM

P: 515-329-8050 E: INFO@IHLEFABRICATIONS.COM